



FARMALL® N & V SERIES TRACTOR SPECIFICATIONS

MODEL	FARMALL 80N	FARMALL 100N	FARMALL 110N	FARMALL 80V	FARMALL 110V
ENGINE					
Туре	4-cylinder FPT, turbocharged & aftercooled				
Displacement	3.4 L (207 cu. in.)				
Gross Engine HP	74 @ 2,300 rpm	98 @ 2,300 rpm	106 @ 2,300 rpm	74 @ 2,300 rpm	106 @ 2,300 rpm
PTO HP	62	86	93	65	93
Emissions	Tier 4 A				
Exhaust Treatment	Cooled Exhaust Gas Recirculation (CEGR) with DOC/PM catalyst & Diesel Particulate Filter (DPF)				
Fuel System	Electronic, high pressure, common rail				
Fuel Capacity	19 gal. (72 L)			17.7 gal. (67 L)	
TRANSMISSION					
Type (Standard/Optional)	Standard: 16 × 16	Synchro Shift/Option 1: 16×16 Powe	r Shift/Option 2: 32×16 Hi-lo Power Sh	nift. All configurations available with optional 28	3 × 16 creeper.
3-POINT HITCH					
Lift Capacity @ 24 In. Behind Pins	3,780 lbs. (1715 kg)				
PTO					
PTO Speeds (Standard/Optional)	540/540E standard / 540/1,000 optional				
HYDRAULICS					
Base Rear Remotes (Standard/Optional)	2 standard/3 optional, with 4th coupler operated via a diverter on remote lever				
Mid-Mount Valves (Optional)	2				
Mid-Mount Motor Coupler	1, flow adjustable to 5 gpm (33 L/min.)				
Main Pump Flow	16.9 gpm (64 L/min.): Cab or Non-cab				
Optional Main Flow Pump	21.1 gpm (80 L/min.): Cab only				
Steering Pump Flow	11.4 gpm (43.3 L/min.)				
DIMENSIONS					
Overall Length Includes Hitch/Drawbar	158 in. (4 015 mm)			152.7 in. (3 879 mm)	
Height to Top of Cab With 380/70R24 Rear Tires	91.7 in. (2 329 mm)				
Height to Top of ROPS With 380/70R24 Rear Tires	90.0 in. (2 287 mm)				
Minimum Ground Clearance with 380/70R24 Rear Tires	11.2 in. (285 mm)				
Wheelbase	96.0 in. (2 438 mm)				
Overall Width	52.9 in. (1342 mm) to 53 in. (1356 mm) tire size dependent			42.5 in. (1 079 mm) to 49 in. (1 245 mm) tire size dependent	
WEIGHT					
Average Weight 2WD (Cab/Non-cab)	5,613 lbs. (2546 kg)/5,300 lbs. (2404 kg)	5,772 lbs. (2618 kg)	(5.498 lbs. (2.494 kg)	5,421 lbs. (2459 kg)/5,108 lbs. (2317 kg)	5,580 lbs. (2531 kg)/5,307 lbs. (240
			-, (=		0,

Hitch shown on front cover is not available in North America.

SAFETY NEVER HURTS!TM Always read the Operator's Manual before operating any equipment. Inspect equipment before using it, and be sure it is operating properly. Follow the product safety signs, and use any safety features provided. CNH Industrial America LLC reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold. Specifications, descriptions and illustrative material herein are as accurate as known at time of publication, but are subject to change without notice. Availability of some models and equipment builds varies according to the country in which the equipment is used.

CASE III
AGRICULTURE